

STORAGE AND
COLLECTION
CONTAINERS
**OVERFILL
PROTECTION**



If containers are filled in such a way that the filling level cannot be identified (i.e. via a fixed line), it has to be ensured that the container cannot be overfilled.

Overfill protection generally includes the following two components:

- › Level sensor permanently mounted in the container with a PTC thermistor changing its electrical resistance on reaching the admissible filling level
- › Transducer generating an optical and acoustic signal from this change in resistance and via which the filling process can also be stopped

For type-specific differences, please refer to the following table.

Scope of delivery:
Level sensor, transducer, mounted at
ordered Rietberg container

INFO



CONTAINERS

Rietbergwerke GmbH & Co. KG
Bahnhofstraße 55
DE-33397 Rietberg

Phone +49 (0)5244 983-200
behaeltertechnik@seppeler.de
www.seppeler.de




STORAGE AND
COLLECTION
CONTAINERS



Type	Description	Art. no.
FIRE-RESISTANT FLUIDS		
SE-Ü-40	1 Transducer, protection type IP 40, with simple bracket mounted at the container. Fully connected	86286
SE-Ü-54	Control cabinet, protection type IP54, with panel-mounted transducer on the container. Fully connected	31195
SE-ÜI-64	Level indicator displayed in percent and height in centimetres with integrated overfill protection, control cabinet protection class IP 64 with transducer for on-site wall mounting, fill-level sensor with float assembled in container	300363
FLAMMABLE FLUIDS		
ELH-Ü-54	IP 54 control cabinet with transducer for mounting outside of the EX zone of the container. Connection between level sensor and control cabinet on-site	31303
ELH-Ü-EEEx-d	Control cabinet with EEx-d housing with transducer, completely panel-mounted on the container and fully connected	85974
ELH-ÜI-64	Level indicator displayed in percent and height in centimetres with integrated overfill protection, control cabinet protection class IP 64 with transducer for on-site wall mounting outside the EX zone, fill-level sensor with float assembled in container	300644

Example for EX zone classification



OPTION I:




Zone 0: Zone 0 is the interior of a storage container including feed and ventilation lines. In this area, dangerous explosive atmospheres occur permanently or frequently.



Zone 1: In this area in the vicinity of openings, dangerous explosive atmospheres may occur occasionally during operation.



Zone 2: In this area at a larger distance to a container, dangerous explosive atmospheres do not occur or only temporarily.



OPTION II:



No EX zone: No flammable vapour/air mixtures



IP 54 control cabinet



Control cabinet with EEx-d housing



Ventilation line